









Draka Elevator Products, Inc.

Member of the Draka Holding Group

Procedure: Whisper-Flex® Cable Stripping

①		Clamp one end of Whisper-Flex Compensating Cable in a vise or other device to hold it securely while the jacket is being removed. Clamp it such that approximately 6-8 inches of the free end is up.
②		Using the recommended cable jacket cutter, score the circumference of the jacket far enough from the cable end to leave 1½ chain links free.
③		Make sure the jacket has been cut through to the depth of the actual chain. Bend back the top of the Whisper-Flex® Cable and run the utility knife along the scoring groove made by the cable jacket cutter.
④		With the utility knife, make a cut lengthwise from the groove created in step ② to the end of the cable. Make sure the jacket has been cut through to the depth of the actual chain.
⑤		Grasp the jacket at one edge of the lengthwise cut with the nippers and pull back, away from the chain. Repeat this step for the other edge of the cut. Repeat steps ③ through ⑤ as needed until the 1½ links are completely free of the jacket.
		Recommended tool kit: Whisper-Flex Cable Field Strip Kit (WF-STRP) Kit contents: Angle mounting bracket, seven (7) clamps, nippers, utility knife, cable jacket cutter, hacksaw, gloves, carrying case.

Tool Usage Instruction WFCS-030601

Draka Elevator Products, Inc. – 2151 North Church Street, P.O. Box 400 – Rocky Mount, NC 27802, USA

Tel: (252) 972-6000 - Fax: (252) 972-6001

Draka Elevator Products, Inc. reserves the right to improve, enhance, and modify the features and specifications of Draka Elevator Products, Inc. products without prior notification.

Draka Elevator Products, the Draka Globe Design, and Whisper-Flex are registered trademarks of Draka Elevator Products, Inc.

©2003 Draka Elevator Products, Inc. All Rights Reserved.